


## Current Tools<sup>™</sup> Model 9548 Four-Sided Roller with Clamp

The Model 9548 Four-Sided Roller is designed to easily clamp to various styles of cable tray and provide low friction wire pulling. This unit also has a quick release pin for ease of unloading the cable or wire bundle into the cable tray.



# **Instruction Sheet**



Read and understand this material before using the Four-Sided Roller. Failure to understand how to safely operate this unit could result in serious injury or death.


This manual is free of charge. All personnel who operate the Four-Sided Roller should have a copy of this manual and read and understand its contents. To request a copy, call or write to the address below.

CURRENT TOOLS • P. O. BOX 17026 GREENVILLE, SC 29606 800.230.5421 or 864.244.1201 • FAX 864.244.5860 www.currenttools.com

## SPECIFICATIONS

Model No.	9548
<b>Opening Size</b>	8"
Capacity	100 lbs.
Weight	9.5 lbs.

### STYPICAL CLAMPING ARRANGEMENTS



#### **OPERATING INSTRUCTIONS**

- 1. Firmly attach Four-Sided Roller to cable tray using clamp provided. Be sure to configure the Four-Sided Roller so that the quick release pin is on the bottom inside position. (*See Figures 1a thru 1c.*)
- 2. Remove the quick release pin and open the Four-Sided Roller to load cable. Close the Four-Sided Roller and re-insert the quick release pin before beginning the pull. After cable pull is complete, remove the quick release pin and unload the cable into the cable tray. (*See Figure 3.*)

